

Q539A, H and J Subbases

Installation Instruction for the Trained Service Technician.

Application

Q539 Subbases provide cooling anticipators, and mounting for T87F Thermostats. Q539 Subbases also provide system and fan switching for heating, cooling, and heating-cooling thermostats. For subbase specifications, refer to Tables 1 and 2.

TABLE 1—SUBBASE SPECIFICATIONS.

Model Description	System Switch	Fan Switch	Terminals	See Fig.
Q539A provides system and fan switching and cooling anticipator for heating cooling systems. Includes indicator LOCKOUT LED for use in oil burner systems.	HEAT - OFF-COOL	AUTO-ON	RH-RC-W-Y-G-X	3
Q539H provides fan switching with Z terminal for low voltage fan switch to control fan in AUTO position.	NONE	AUTO-ON	R-W-Y-G-X-Z	4
Q539J provides system switching for control of heating and cooling for heat pump and electric heating. Auto fan operates through fan relay on both heating and cooling.	HEAT - OFF-COOL	AUTO-ON	R-W-Y-G-X-P-O-B	5

TABLE 2—TERMINAL DESIGNATIONS.

Terminal	Connection
R	Transformer.
RC ^a	Cooling Transformer.
RH ^b	Heating Transformer.
W	Heating Relay or Valve Coil.
Y	Cooling Contactor Coil.
B ^c	Heating Damper Motor or Changeover Valve (if used).
O ^d	Cooling Damper Motor or Changeover Valve (if used).
G	Fan Relay Coil.
X ^e	Clogged Filter Switch or Lockout Switch (primary control).
P	Heat Pump Contactor Coil.
Z	Q539H low voltage fan switch for control of fan relay in AUTO position for both heating and cooling control.

^a Cooling transformer in systems with separate heating and cooling circuits.

^b Heating transformer in systems with isolated heating and cooling circuits.

^c Circuit only completed between R and B with system switch in HEAT position.

^d Circuit only completed between R and O with system switch in COOL position.

^e Only available on subbases with indicator LEDs.



Mercury Notice

This control contains mercury in a sealed tube. Do not place control in the trash at the end of its useful life.

If this control is replacing a control that contains mercury in a sealed tube, do *not* place your old control in the trash.

Contact your local waste management authority for instructions regarding recycling and the proper disposal of this control, or of an old control containing mercury in a sealed tube.

Installation

WHEN INSTALLING THIS PRODUCT...

1. Read these instructions carefully. Failure to follow instructions can damage product or cause a hazardous condition.
2. Check ratings given in instructions and on product to make sure product is suitable for your application.
3. Make sure installer is a trained, experienced service technician.
4. After completing installation check out product operation as provided in these instructions.

LOCATION

Locate the subbase about 5 ft (1.5m) above the floor in an area with good air circulation at average temperature.



Do not mount the subbase where it may be affected by:

- drafts or dead spots behind doors or in corners.
- hot or cold air from ducts.
- radiant heat from the sun, fireplaces, or appliances.
- concealed pipes and chimneys.
- unheated (uncooled) areas such as an outside wall.

! CAUTION

- Disconnect power supply to prevent electrical shock or equipment damage.
- Do not short across coil terminals on relay, this can burn out the thermostat heat anticipator.
- Do not overtighten captive mounting screws because damage to subbase threads can result.

MOUNTING AND WIRING

Disconnect power supply before beginning installation to prevent electrical shock or equipment damage.

All wiring must comply with local codes and ordinances.

1. In replacement applications, check the existing subbase wires for cracked or frayed insulation. Replace any wires in poor condition. If the wire is plastered into the wall, make a hole next to the wires and loosen the wires so that the wires can be pushed back into the wall later.
2. In new installations, run wiring (if necessary) to the subbase location.

IMPORTANT: *To prevent interference with the thermostat linkage, keep wire length to a minimum and run wires as close as possible to the subbase.*

3. Connect the wires to the terminals inside the subbase. Refer to equipment manufacturer instructions for Q539 wiring diagrams. If not available, refer to Fig. 1 through 5.
4. Push excess wire back through the hole and plug any opening with insulation to prevent drafts that can affect performance.
5. Loosely fasten the thermostat subbase to the wall with a screw through the left mounting hole. Adjust the subbase so it is approximately level and start the second screw through the right mounting slot. Do not tighten.
6. Level the thermostat subbase using a spirit level as shown in Fig. 1.
7. Tighten mounting screws.

IMPORTANT: *An incorrectly leveled subbase will cause the temperature control to deviate from setpoint.*

8. Mount and wire the thermostat to the thermostat subbase using the equipment manufacturer's instructions.

Fig. 1—Level Q539 using a spirit level .




Fig. 2—Barrier configuration.





Fig. 3—Typical hookup for Q539A in heating-cooling application with remote lockout indication.



COOLING



CAUTION

If outside air or heat exchange medium (water) is below 10°C (50°F), do not operate cooling.

Move the system switch on the Q539 to COOL and the fan switch to AUTO. Move the cooling setpoint dial to about 6°C (10°F) below room temperature. Cooling equipment should start and the fan should run. Change the setpoint to about 6°C (10°F) above the room temperature. The cooling equipment and fan should shut off.

FAN

Move the subbase switch to OFF and the fan switch to ON. The fan should run continuously. Move the fan switch to AUTO. In this position, fan operation is controlled by the heating or cooling system control circuit.

Operate the entire system one complete cycle with switches in each position before leaving installation. Turn thermostat dial to the desired setting and set the system and fan switches.

Honeywell

Automation and Control Solutions

Honeywell
1985 Douglas Drive North
Golden Valley, MN 55422

Honeywell Limited—Honeywell Limitée
35 Dynamic Drive
Scarborough, Ontario
M1V 4Z9

